

Shift and control rod adjustment (© G.M.C.)

rear bearing cap; then remove cap.

2. Remove cap screws attaching front bearing cap; then remove cap and shims. Attach shims to cap for reassembly.
3. Press or drive out input shaft toward front of case.
4. Remove direct drive gear, sliding gear and thrust washer from inside case.
5. Remove front bearing and washer. Remove other bearing from shaft.

Assembly

During assembly, it is important that all parts are cleaned and lubricated to prevent deterioration before it is placed in service. Use new gaskets, oil seals, snap-rings and lock washers.

Input Shaft

1. Press front bearing onto shaft with shielded side of bearing toward shoulder on shaft. Insert shaft through opening in front of case and as shaft is being moved into position, install sliding gear, washer, direct drive gear and washer. Install rear bearing on shaft with shielded side toward inside. Install gasket and bearing cap at rear of case. Tighten cap screws securely. At front of case, install bearing cap and shims. Use same thickness of shims as removed during disassembly. Install U-joint yoke and nut. Tighten nut firmly and install cotter pin.

Rear Output Shaft

1. Press bearing cone onto rear output shaft.
2. Press or drive rear output shaft in case through shaft gear.
3. Press or drive bearing cup into case. Install bearing cap, using same thickness of shims that were removed. Tighten cap screws firmly.
4. At rear of shaft, press bearing cone onto shaft and bearing cup into case. Install speedometer drive gear.
5. Install new oil seal in bearing cap; then install gasket and cap with screws.
6. Install U-joint yoke and secure with nut. Tighten nut firmly and install cotter pin.
7. Check end play of shaft, using dial indicator. Remove or add adjusting shims as required until end play is as near zero as possible.

Front Output Shaft

1. Place front output gear inside case; then install bearing over gear hub and into position in case.
2. Press bearing onto output shaft.
3. As output shaft is installed through opening in front of case, sliding gear must be located on shaft as shaft is pushed into its proper position.
4. Install new oil seal in bearing cap; then install gasket and cap with screws.
5. Install spacer on gear; then install snap-ring.
6. Install gasket and bearing cap.

Secure with cap screws.


7. Install U-joint yoke and secure with nut. Tighten nut securely and install cotter pin.

Idler Shaft

1. Press bearing cone onto front end of idler shaft.
2. Start idler shaft into front side of case and install low speed gear, spacer, constant mesh gear and bearing cone as shaft is pushed into position.
3. Press bearing cups into case and over bearing cones.
4. At rear of case, install bearing cap and gasket with cap screws.
5. At front of case, install bearing cap and adjusting shims with cap bolts. NOTE: Make sure adjusting shims used are same thickness as shims removed.
6. Check end play of shaft, using dial indicator. Subtract or add adjusting shims as required until end play is as near to zero as possible.

Cover and Shift Rod

1. Install oil seals in case.
2. Push shift rods into case with caution, so as not to damage oil seals.
3. Install shift forks on respective shift rods. Install set screws attaching forks to rods. Twist safety wire around shift rods and then through hole in set screw.
4. Insert detent balls and springs into holes in case.
5. Slide interlock pin into bosses on inner surface of cover. Install gasket on case with sealing compound. Press end of cover down; then slide cover upward and press into position. Secure with cap screws.



Timken model 221 transfer case (© G.M.C.)

- | | | | |
|----------------------|-------------------|----------------------|-----------------------|
| 1 Shift fork | 17 Oil seal | 33 Speedometer gear | 65 Front output gear |
| 2 Shift rod | 18 Cap screw | 34 Bearing cup | 66 Set screw |
| 3 Oil seal | 19 U-Joint yoke | 35 Bearing cone | 67 Shift fork |
| 4 Cap screw | 20 Nut | 36 Rear output gear | 68 Shift rod |
| 5 Lock washer | 21 U-Joint yoke | 37 Rear output shaft | 69 Front sliding gear |
| 6 Bearing cap | 22 Oil seal | 38 Bearing cone | 70 Front output shaft |
| 7 Gasket | 23 Cap screw | 39 Bearing cup | 71 Bearing |
| 8 Transfer case | 24 Flat cap screw | 40 Adjusting shims | 72 Gasket |
| 9 Bearing | 25 Lock washer | 41 Bearing Cap | 73 Bearing cap |
| 10 Washer | 26 Bearing cap | 42 Lock washer | 74 Lock washer |
| 11 Direct drive gear | 27 Gasket | 43 Cap screw | 75 Cap screw |
| 11A Input shaft gear | 28 Breather | 44 Cap screw | 76 Oil seal |
| 12 Input shaft | 29 Cover | 45 Lock washer | 77 U-Joint yoke |
| 13 Bearing | 30 Interlock pin | 46 Bearing cap | 78 Nut |
| 14 Adjusting shims | 31 Spring | 47 Gasket | |
| 15 Bearing cap | 32 Detent ball | 48 Bearing cup | |
| 16 Lock washer | | | |
| | | 49 Bearing cone | |
| | | 50 Input shaft gear | |
| | | 51 Idler shaft | |
| | | 52 Spacer | |
| | | 53 Low speed gear | |
| | | 54 Bearing cone | |
| | | 55 Bearing cup | |
| | | 56 Adjusting shims | |
| | | 57 Bearing cap | |
| | | 58 Lock washer | |
| | | 59 Cap screw | |
| | | 60 Bearing cap | |
| | | 61 Gasket | |
| | | 62 Snap ring | |
| | | 63 Spacer | |
| | | 64 Bearing | |