



Another thick washer, just like the one your truck had stock, is re-installed at the bottom of the lower mount. A nut is then attached to the bolt that slides through the entire assembly from the cab floor. Tighten the nut enough to secure the assembly, but do not overtighten until you have finished the process on the other side of the truck.