



With the core support remove (done for photo purposes only), you can clearly see what the ne mounts look like when they are properly install. Now, simply reinstall the mounting bolt & you're all done and riding down the road in greater comfort.