



PEAK

INSTRUCTIONS:

HOOD OPENING

1. ALIGN TEMPLATE WITH HOOD OPENING & PEAK LINES. TAPE TEMPLATE SECURELY.
2. SCRIBE CENTER LINES USING HEAVY MARKS ON HOLE EDGE & SCRIBE OUTLINE OF HOLE & NOTCH.
3. REMOVE TEMPLATE, CENTER PUNCH & DRILL 1.12 DIA. HOLE.
4. ENLARGE HOLE TO SCRIBE LINE & FILE INDEX NOTCH.

1993A

