


The 18-pin connector:



- | | |
|---------------------------------------|--|
| 1 Panel lamp input | 10 Anti-Lock indicator lamp |
| 2 Hot (+12V gauge power) | 11 Service Engine Soon indicator lamp |
| 3 Generator indicator lamp | 12 Hot (+12V for Voltmeter) |
| 4 Upshift | 13 DRL indicator |
| 5 E-Brake light | 14 Speedometer input |
| 6 Coolant temp. input | 15 Fasten seat belts lamp |
| 7 right turn signal ind. | 16 High-Beam indicator lamp |
| 8 Fuel sensor input | 17 Ground |
| 9 Oil pressure input | 18 Left turn signal ind |