
PCM Blue 19 to 15a fused ign source
PCM
Wipers
To Tail Lights
Fuel Pump
Fan 1
Fan 2
Bank 1/2 O2's / MAF / Evap purge
IGN 1
IGN 2
Head / High / 4x4 Lights
175 Amp
4ga To Starter
4ga
10ga
14ga
30A Breaker
120A Breaker
To Fuse Panel wire#2
To IGN 2
To IGN 1
To HEI wire at fuse panel (IGN & on at start)
To Choke wire at fuse panel (IGN off at start)
To MAF Sensor
To O2 sensor bank 2
To O2 sensor bank 1
Stock Fuse Panel
Water Temp
Starter Solenoid
Oil Pressure
Fuel Pump
Rt Marker/signal
Pwr Pri Markers
Lt Marker/signal
Brake Pressure
Head Lights Low
Head Lights High
TO High Beam / 4x4 Lights
TO DRL / Low Beam
TO Fan 1
TO Fan 2